




Rocker Arms — Manual Inspection

1. Remove the ignition coil covers (see page 6-15).
2. Remove the ignition coils (see page 6-15).
3. Remove the cylinder head covers.

NOTE: Refer to pages 6-49, 6-50 when installing the cylinder head cover.

4. Set the No. 1 piston at top dead center (TDC) (see page 6-19).
5. Push the mid rocker arms on the No. 1 cylinder manually.
6. Check that the mid rocker arms move independently of the primary and secondary rocker arms.



7. Check the mid rocker arms of each cylinder at TDC.
 - If a mid rocker arm does not move, remove the mid, primary and secondary rocker arms as an assembly and check that the pistons in the mid and primary rocker arms move smoothly.
 - Replace the rocker arms as an assembly if there is any abnormality.