




Pressure Plate, Clutch Disc

Removal

1. Remove the transmission (see [section 13](#)).
2. Install the special tools.



3. To prevent warping, unscrew the pressure plate mounting bolts two turns at a time in a crisscross pattern, then remove the pressure plate.



4. Remove the release bearing from the pressure plate.

5. Remove the clutch disc and special tools.

