




Countershaft Bearing (Clutch Housing)

Replacement


1. Remove the bearing retaining plate.




2. Remove the needle bearing with the special tool, then remove the oil guide plate.

**3/8" - 16
SLIDE HAMMER**
(Commercially
available)

**ADJUSTABLE BEARING
PULLER, 25-40 mm**
07736-A01000A




3. Position the oil guide plate and new needle bearing in the bore of the clutch housing. Position the needle bearing with the oil hole facing up.
4. Drive the needle bearing using the special tools.



DRIVER
07749-0010000

ATTACHMENT, 62 x 68 mm
07746-0010500



5. Install the bearing retaining plate, and stake the bolt heads in the groove in the bearing retaining plate.

6 x 1.0 mm SPECIAL BOLT
12 N·m (1.2 kgf·m, 9 lbf·ft)
Replace.

