

Mainshaft/Countershaft Speed Sensors

Replacement

1. Remove the 6 mm bolt from the transmission housing, then remove the mainshaft and countershaft speed sensors.
2. Replace the O-ring with a new one before reassembling the mainshaft and countershaft speed sensors.
3. Install the washer only on the countershaft speed sensor. Do not install the washer on the mainshaft speed sensor.
4. Install the speed sensor(s) in the transmission housing.

