



Interlock System

Key Interlock Solenoid Test

1. Remove the dashboard lower cover, and disconnect the floor wire harness connectors.



2. Disconnect the 8P connector from the floor wire harness.



3. Check for continuity between the terminals in each switch position according to the table.

Terminal		A	B	C
Position				
Ignition switch ACC (I)	Key pushed in	○	○	○
	Key released	○	○	

4. Check that the key cannot be removed with power and ground connected to the C and B terminals.
- If the key cannot be removed, the key interlock solenoid is OK.
 - If the key can be removed, replace the steering lock assembly (key interlock solenoid is not available separately).