

Follow the Normal Conditions Maintenance Schedule if the severe driving conditions specified in the Severe Conditions Maintenance Schedule on pages 4-6 and 4-7 do not apply.

Service at the indicated distance or time whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120	NOTE	SECTION and PAGE
	km x 1,000	24	48	72	96	120	144	168	192		
	months	12	24	36	48	60	72	84	96		
Replace engine oil		Every 7,500 miles (12,000 km) or 1 year								Capacity for change with filter: 5.0 ℓ (5.3 US qt, 4.4 Imp qt)	8-2*2
Replace engine oil filter		●	●	●	●	●	●	●	●		8-5*1
Check engine oil and coolant		Check oil and coolant at each fuel stop								Check levels and check for leaks.	8-4*1, 10-2*1
Replace air cleaner element			●		●		●		●		11-149*1
Inspect valve clearance		Adjust only if noisy						●		Intake: 0.15 – 0.19 mm (0.006 – 0.007 in)** Exhaust: 0.17 – 0.21 mm (0.007 – 0.008 in)** Measured when cold	6-10*1
Replace spark plugs								●		NGK: PFR6L-11 DENSO: PK20PR-L11 Gap: 1.0 – 1.1 mm (0.039 – 0.043 in)**5	23-96*1
Replace timing belt and inspect water pump								●			6-14*1, 10-11*1
Inspect and adjust drive belts			●		●		●		●	Check for cracks and damage. Check deflection and tension at center of following belts pressing with 98 N (10 kgf, 22 lbf) tension: Alternator drive belt: 11.0 – 13.5 mm (0.43 – 0.53 in) A/C compressor belt: 10 – 12 mm (0.39 – 0.47 in)	22-88*1 23-109*1
Replace fuel filter*					●				●		11-138*1
Inspect idle speed								●		800 ± 50 rpm (M/T: neutral) 780 ± 50 rpm (A/T: N or P position)	11-129*1
Replace engine coolant		At 120,000 miles (192,000 km) or 10 years, then every 60,000 miles (96,000 km) or 5 years								Capacity for change: 12.0 ℓ (12.7 US qt, 10.6 Imp qt) Check specific gravity for freezing point.	10-2*3
Replace transmission fluid	M/T	Replace every 120,000 miles (192,000 km) or 6 years								Honda MTF 2.65 ℓ (2.80 US qt, 2.33 Imp qt) for change	13-3*1
	A/T	At 120,000 miles (192,000 km) or 6 years, then every 90,000 miles (144,000 km) or 5 years								2.9 ℓ (3.1 US qt, 2.6 Imp qt) for change. Use Honda ATF-Z1 (ATF)	14-105*1
Inspect front and rear brakes		●	●	●	●	●	●	●	●	• Check the brake pads, disc thickness, and free movement. • Check the calipers for leakage.	19*1-4, 19-6, 19-7 19-10, 19-11, 19-17, 19-19, 19-20, 19-21
Replace brake fluid (Including ABS)		Every 3 years								Use Honda DOT3 brake fluid. Check that the brake fluid level is between the upper and lower marks on the reservoir.	19-11*1
Check parking brake adjustment		●	●	●	●	●	●	●	●	Fully engaged 10 to 14 notches.	19-5*1
Check tire inflation and condition at least once per month		Every 7,500 miles (12,000 km)								The suggested rotation method is shown in the diagram in the Owner's Manual.	—

*1: Refer to Service Manual ('97 NSX, P/N 61SL006)

*2: Refer to Service Manual ('98 NSX, P/N 61SL007)

*3: Refer to Service Manual ('01 NSX, P/N 61SW000)

*4: Measured between the rocker arm and camshaft

*5: Do not adjust the gap, replace spark plug if it is out of specification

Service at the indicated distance or time whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120	NOTE	SECTION and PAGE*1
	km x 1,000	24	48	72	96	120	144	168	192		
	months	12	24	36	48	60	72	84	96		
Visually inspect the following items:											
Tie-rod ends, steering gear box, and boots	●	●	●	●	●	●	●	●	●	Check steering linkage for looseness. Check condition of boots. Check for fluid leaks.	17-57
Suspension components										Check the bolts for lightness. Check the condition of ball joint boots.	18-14,18-15, 18-30,18-31
Driveshaft boots										Check condition of the boots.	16-3
Brake hoses and lines (including ABS)										Check for damage or leakage.	19-4,19-27
All fluid levels and condition of fluid										Check levels, condition of fluids, and check for leaks. If brake fluid is low, check brake pad thickness.	10-2, 13-3, 14-105 19-84
Cooling system hoses and connections										Check all hoses for damage, leaks, and deterioration. Check for proper fan operation.	10-2
Exhaust system*										Check the catalytic converter heat shield, exhaust pipe, and muffler for damage, leaks, and lightness.	9-6,9-7
Fuel lines and connections*										Check for leaks. Retighten loose connections and replace any damaged parts.	11-130

*1: Refer to Service Manual ('97 NSX, P/N 61SL006)

* According to state and federal regulations, failure to perform maintenance on the items marked with an asterisk (*) will not void customer's emission warranties. However, Honda recommends that all maintenance services be performed at the recommended time or mileage period to ensure long-term reliability.

For 2002 Canada model: Follow the Severe Conditions Maintenance Schedule for 2002 Model on page 4-6 and 4-7.

