


Oil Seal

Installation

1. Install the oil seal into the transmission housing using the special tools.



2. Install the oil seal into the torque converter housing using the special tools.

