





### EVAP Control Canister Removal/Installation

1. Remove the air cleaner housing.
2. Remove the engine compartment fuse/relay box mounting bolts and harness clip.



3. Remove the EVAP control canister bracket mounting bolts.
4. Disconnect the hoses and connector from the EVAP control canister.
5. Remove the dust filter from the dust filter bracket.
6. Remove the EVAP control canister and brackets.



7. Install the EVAP control canister in the reverse order of removal.