

Cruise Control

Main Switch Test

- 1. Remove the dashboard lower cover (see page 23-307).
- 2. If necessary, remove the dashboard lower pad.
- 3. Disconnect the 20P connector, and check for continuity between the terminals, in each switch position, according to the table.

Terminal Position	M	L		B	H		G
OFF		○	⊗	○	○	⊗	○
ON	○	○	⊗	○	○	⊗	○

