




Switch Test

- 1. Remove the dashboard lower cover (see page 23-287).
- 2. If necessary, remove the dashboard lower pad.
- 3. Disconnect the 18P connector from the floor wire harness.
- 4. Check for continuity between the terminals in each switch position according to the table.



Terminal	B	I	H		R	A		Q
Position								
PUSHED								
RELEASED								

