


Interlock System

Parking Pin Switch Test/Replacement

1. Remove the center console panel and dashboard (see [section 20](#)).
2. Disconnect the 2P connector of the parking pin switch from the floor wire harness.
3. Check for continuity between the terminals in each switch lever position according to the table.

Terminal		A	B
Position			
Push button	Pressed		
	Released		



4. If necessary, replace the parking pin switch.

5. Remove the self-locking nut and parking pin switch.

