



Timing Belt

Illustrated Index

NOTE:

- Refer to page 6-18 for positioning crankshaft and pulley before installing the belt.
- If it is to be reused, mark the direction of rotation on the belt before removing it.
- Do not use the middle cover and lower cover to store removed items.
- Clean the middle cover and lower cover before installing them.
- Replace the camshaft seals and crankshaft seals if there is oil leakage.
- Refer to page 6-12 before installing timing belt.

