


Seat Belt Tensioner Handling and Storage

Do not try disassemble the seat belt tensioner assembly. It has no serviceable parts. Once seat belt tensioner has been operated, it cannot be repaired or reused.



- Store the removed seat belt tensioner assembly on a secure flat surface away from any high heat source (exceeding 212°F/100°C) and free of any oil, grease, detergent or water.

- Follow these precautions below during removal of a tensioner.

- Install its short connector (RED) as soon as the tensioner connector is disconnected.
- Use only the test equipment specified in the Electrical section.
- Do not disassemble the tensioner or allow any impact to it.

For proper disposal see page [24-37](#).