

Lighting System

HID Bulb Removal


⚠ WARNING

A transient high tension (25,000 V) occurs at the bulb sockets of the high intensity discharge (HID) lamps when the combination light switch is turned ON. It may cause serious electrical shock or electrocution if you do not observe the cautions below.

⚠ CAUTION

- Never turn on the combination light switch before fitting the HID bulbs to their bulb sockets and completing the reassembly of the headlight assemblies.
- Do not service the headlight assemblies in wet conditions, such as rain or snow, near a sprinkler system, or when your heads are wet to prevent electrocution.
- Do not touch the surface of the HID bulbs with your bare hand and do not stain them with any oils.
- Do not disassemble the inverter unit and the ignitor unit.
- Do not turn on the HID bulb by using a power source other than the battery mounted in your vehicle.


1. Make sure you have the anti-theft code for the radio, then write down the frequencies for the radio's preset buttons.
2. Turn the combination light switch OFF.
3. Disconnect the battery negative cable, then disconnect the positive cable.
4. Remove the Torx bolt using a Torx T20 bit.



5. Turn the cover 45° counterclockwise to remove it from the headlight assembly.



6. Turn the socket 45° counterclockwise to remove it from the bulb.
7. Pull the retaining spring away from the bulb (B), then remove the bulb.



8. Install the new bulb in the reverse order of removal.
9. After reconnecting the battery, enter the anti-theft code for the radio, then enter the customer's radio station presets.