


Stereo Sound System

Power Antenna Motor Replacement

1. Open the trunk lid, and remove the side trim panel.
2. Disconnect the 4P connector and antenna lead from the motor, then remove the antenna nut and three mounting bolts, and take out the motor with the antenna mast.

NOTE: Check the O-ring for deformation and damage. If necessary, replace it to prevent a leak.



3. Install in the reverse order of removal.

NOTE: Tighten the antenna nut, then tighten the three motor bracket mounting bolts.