


Cruise Control

Brake Switch Test

1. Disconnect the 4P connector from the switch.




2. Check for continuity between the terminals according to the table.

Terminal	A	B	C	D
Brake pedal				
RELEASED	○			○
PUSHED		○	○	

3. If necessary, replace the switch or adjust pedal height (see [section 19](#)).

Clutch Switch Test

1. Disconnect the 3P connector from the switch.



2. Check for continuity between the terminals according to the table.

Terminal	B	C
Clutch pedal		
RELEASED	○	○
PUSHED		

3. If necessary, replace the switch or adjust pedal height (see [section 12](#)).