


Trunk Opener

Opener Switch Test


1. Remove the driver's door panel, then push the switch out of the door panel as shown.




2. Check for continuity between the terminals.
 - There should be continuity between the A and B terminals when the switch is pushed.
 - There should be no continuity when the switch is released.

Solenoid Test/Replacement

1. Open the trunk lid, and remove the trunk side trim panel.
2. Disconnect the 2P connector from the solenoid assembly, and test solenoid operation by connecting battery power and ground to the A and B terminals momentarily.



3. To remove the solenoid, remove the two bolts, then disconnect the trunk opener cable from the solenoid assembly.



4. Install in the reverse order of removal.