


Radiator and Condenser Fan Controls

Radiator Fan Control Sensor Test

NOTE: Bleed air from the cooling system after installing the radiator fan control sensor (see [section 10](#)).

- 1. Remove the radiator fan control sensor from the thermostat cover.
- 2. Suspend the radiator fan control sensor in a container of coolant as shown.



- 3. Heat the coolant, and check coolant temperature with a thermometer (see table below).
- 4. Measure the resistance between the A and B terminals according to the table.

Temperature	183°F (84°C)	194°F (90°C)	226°F (108°C)	230°F (110°C)
Resistance (KΩ)	1.047 – 1.255	0.872 – 1.024	0.519 – 0.573	0.489 – 0.541

- 5. If unable to obtain the above readings, replace the radiator fan control sensor.