

Rear Damper

Reassembly


1. Install the damper unit on a spring compressor.
2. Assemble the damper in reverse order of removal except the damper mounting washer and self-locking nut.

NOTE: Align the bottom of damper spring and spring lower seat.

STRUT SPRING COMPRESSOR:

(Commercially available)

BRANICK T/N MST-580A, T/N 7200 or equivalent




SPRING LOWER SEAT


3. Position the damper mounting base so that the angle of the stud bolts is as shown.

NOTE: Follow the manufacture's instructions.

DAMPER MOUNTING BASE



4. Compress the damper spring.
CAUTION: Do not compress the spring more than necessary to install the self-locking nut.
5. Install the damper mounting rubber and damper mounting washer, and loosely install a new self-locking nut.
6. Hold the damper shaft, and tighten the self-locking nut.



SELF-LOCKING NUT

10 x 1.25 mm

Replace.

29 N-m (3.0 kgf-m, 22 lbf-ft)

DAMPER

MOUNTING WASHER