




# Master Switch Test

- 1. Remove the door panel (see [section 20](#)).
- 2. Disconnect the 12P connector.
- 3. Check for continuity between the terminals in each switch position according to the tables.



View from wire side

## Driver's Switch

Terminal	2	5	1	12
Position				
UP	○	○		
OFF				
DOWN		○	○	
DOWN (AUTO)		○	○	○

## Passenger's Switch

Terminal	4	11	9	10
Position				
UP	Main Switch			
	ON	○	○	○
OFF	ON	○	○	○
	OFF	○	○	○
DOWN	ON	○	○	○
	OFF	○	○	○

## Switch Light

B	7
○	○