

# Roof


## Lock Receivers Replacement

1. Remove the roof.
2. Remove the front and rear roof rail trim (see page 20-79).
3. Disconnect the connector, and detach the harness clip (rear lock receiver). Remove the bolts, then remove the front and rear lock receivers.
4. Installation is the reverse of the removal procedure.

### NOTE:


- Make sure the connector is connected properly.
- Adjust the lock receivers alignment.

### ►: Bolt locations, 8



8 x 1.25 mm  
22 N·m (2.2 kgf·m,  
16 lbf·ft)

Front:



Rear:

