


Sunlight Sensor

Removal

Protect the dashboard with a shop towel, then with a small screwdriver, carefully pry the sunlight sensor out of the dashboard and disconnect its connector.

SUNLIGHT
SENSOR



Test

Measure the voltage between the terminals with the sensor out of direct sunlight.

- With the connector connected (probe the back of it): 1.4 ± 0.2 V
- With the connector disconnected: 0.1 - 0.2 V

