


Front/Rear Speaker Replacement


Front speaker:

1. Remove the door panel (see [section 20](#)).
2. Remove the door speaker assembly from the door panel by removing the five screws.




Rear speaker:

1. Remove the speaker grille.
2. Remove the four screws, then disconnect the 2P connector from the speaker.



Foot Well Bass Speaker Replacement

1. Pull back the carpet on the passenger's side.
2. Remove the foot well bass speaker cover.



3. Disconnect the 2P and 6P connectors, then remove the two bolts, and remove the foot well bass speaker assembly.

