


Seat Belt Tensioner Removal


CAUTION:

- Do not install used SRS parts from another car: use only new SRS parts.
- Carefully inspect the seat belt tensioner before installing it. Do not install a tensioner that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.
- The shoulder harness anchor bolt must be removed before you remove the tensioner.
- After completing repair work, be sure to remove SRS Service Connector.

1. Before disconnecting any part of the SRS wire harness, install the short connectors (RED) (see page 24-10).
2. Remove the rear trim panel, upper trim panel, rear side trim panel, and rear pillar trim panel.



3. Disconnect the 3P connector from the seat belt tensioner, then install the short connectors (RED) on the seat belt tensioners.



4. Remove the shoulder harness anchor bolt, then remove the two seat belt tensioner mounting bolts and tensioner.

