

Shift Fork Assembly

Disassembly/Reassembly

NOTE: Install the spring pins so their grooves are 180° apart.

 Prior to reassembling, clean all the parts in solvent, dry them, and apply lubricant to any contact surfaces.

Disassembly: Remove the 3 mm spring pin and 5 mm spring pin.

Reassembly: Install the 5 mm spring pin first, then install the 3 mm spring pin.

