




Countershaft Assembly

Index

NOTE: The 3rd, 4th, 5th and 6th gears are installed with a press.

 Prior to reassembling, clean all the parts in solvent, dry them, and apply lubricant to any contact surfaces. The 3rd, 4th, 5th and 6th gears should be installed without lubrication using a press.

