

Engine Cover/Roof Cover

Replacement

NOTE:

- Take care not to scratch the body.
- Open the rear hatch.

Roof cover (Engine cover) removal:

1. Open the roof cover, remove the nuts, then remove the roof cover.

●: Nut locations, 4



6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)

STRIKER


ROOF COVER

ROOF COVER
LATCH


NOTE: After installing the roof cover, adjust the roof cover latch by using shims to make the roof cover lock securely (see page 20-113).

2. If removing the engine cover, remove the ground wire, disconnect the roof holder switch connector, then detach the harness clip from the left side (see page 20-111). Remove the nuts, then remove the engine cover.

●: Nut locations, 4



ENGINE COVER



ENGINE
COVER
HINGE

NUTS

6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)

3. Installation is the reverse of the removal procedure.




NOTE: Make sure the roof cover opens properly and locks securely.



Opener/Latch/Opener cable/Hook stop/Roof stop bracket removal:

1. Open the engine cover. Remove the screws, then remove the support rod bracket. Remove the push nuts, then remove the engine cover insulator.

►: Screw locations, 2 ▷: Push nut locations, 19



2. Remove the roof cover latch, roof cover opener and roof cover opener cable from the engine cover.




NOTE: Take care not to bend the roof cover opener cable.

●: Nut locations, 5

►: Screw locations, 2



6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)




(cont'd)

Engine Cover/Roof Cover

Replacement (cont'd)





3. Remove the roof stop brackets and hook stops from the engine cover.



►: Screw locations

A ►, 3 Left, 1 Right, 2


B ►, 1 Left only.



●: Nut locations, 4



6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)



4. Installation is the reverse of the removal procedure.

NOTE:

- Make sure the roof cover opens properly and locks securely.
- Make sure the roof fits on the engine cover securely.

