


Supplemental Restraint System (SRS)

Seat Belt Tensioner Installation


CAUTION:

- Be sure to install the harness wires so that they are not pinched or interfering with other parts.
- Be sure the battery cables are disconnected.


1. Install the seat belt tensioner.



2. Reinstall the shoulder harness anchor bolt.
3. Remove the short connector (RED) from the tensioner, then connect the floor wire harness connector to the tensioner.



4. Reinstall the rear pillar trim panel, rear side trim panel, upper trim panel, and rear trim panel.



5. Remove the short connector (RED) from the passenger's airbag, and remove the SRS Service Connector from the SRS main harness.
6. Reconnect the passenger's airbag 3P connector to the SRS main harness 3P connector, then reinstall the glove box.
7. Remove the short connector (RED) from the driver's airbag, and remove the SRS Service Connector A from the cable reel connector.
8. Reconnect the driver's airbag 3P connector to the cable reel 3P connector. Attach the short connector (RED) to the access panel, then reinstall the panel on the steering wheel.
9. Reconnect the battery positive cable, then the negative cable.
10. After installing the seat belt tensioner, confirm proper system operation.
 - Turn the ignition switch ON (II); the SRS indicator light should come on for about six seconds and then go off.
 - Confirm operation of the seat belt retractor.