





Trunk Latch Switch Test

1. Open the trunk lid, and remove the trunk rear trim panel.
2. Disconnect the 3P connector from the trunk latch.




3. Check continuity at the trunk latch connector terminals.
 - There should be continuity between the B and C terminals with the trunk lid open.
 - There should be no continuity between the B and C terminals with the trunk latch in LOCK (trunk lid closed) position.



Door Switch Test

1. Remove the door panel (see [section 20](#)).
2. Disconnect the 2P connector from the door lock actuator assembly.



3. Check continuity at the door switch connector terminals.
 - There should be continuity between the A terminal and B terminal with the door open.
 - There should be no continuity between the A and B terminals with the switch pushed (door closed).

