





Shift Cable

Adjustment


1. Raise the vehicle (see [section 1](#)).
2. Shift to the **N** position.
3. Remove the shift cable cover.
4. Remove the control lever pin and lock pin from the control lever.




5. Shift the control lever to the **N** position.



6. Check that the hole in the control lever is perfectly aligned with the hole in the shift cable.



7. If the hole is not perfectly aligned, loosen the locknut on the shift cable and adjust if as needed.



8. Tighten the locknut.
9. Install the control lever pin and lock pin.

NOTE:

- If you feel the control lever pin binding as you reinstall it, the cable is still out of adjustment and must be readjusted.
- Install the lock pin as shown in step 4.

10. Install the shift cable cover.
11. Start the engine, and check the shift lever in all gears. If any gear does not work properly, refer to Troubleshooting on pages [14-98](#) thru [14-101](#).