

Shift Cable

Removal/Installation

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS (section 24) before performing repairs or service.

⚠ WARNING Make sure lifts are placed properly (see section 1).

1. Remove the center console panel (see section 20).
2. Remove the shift cable by removing the cotter pin and shift lever pin from the shift lever. Remove the mounting bolts from the bracket beam.
3. Remove the shift cable clamp.
4. Remove the shift cable holder and shift cable cover.
5. Remove the shift cable by removing the lock pin and control lever pin from the control lever.

CAUTION: Take care no to bend the cable when removing it.

6. Install the shift cable in the reverse order of removal.
7. After installation, check the cable adjustment (see page 14-171).

