


Security Alarm System

Ignition Key Switch Test

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.

1. Remove the dashboard lower cover, and disconnect the connectors.



2. Disconnect the 8P connector from the floor wire harness.
3. Check continuity at the switch connector terminals.
 - There should be continuity between the No. 8 and No. 7 terminals with the ignition key inserted into the ignition key cylinder.
 - There should be no continuity between terminals No. 8 and No. 7 with the ignition key removed.

