

Supplemental Restraint System (SRS)

Cable Reel Removal


⚠ WARNING Store a removed airbag assembly with the pad surface up. If the airbag is improperly stored face down, accidental deployment could propel the unit with enough force to cause serious injury.

CAUTION:


- Carefully inspect the airbag assembly before installing it. Do not install an airbag assembly that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.
- Always keep the short connectors (RED) on the airbags when the harness is disconnected.
- Do not disassemble or tamper with the airbag assembly.

1. Disconnect the battery negative cable and then the positive cable.
2. Before disconnecting any part of the SRS wire harness, install the short connectors (RED) (see page 24-10).
3. Make sure the wheels are aligned straight ahead.


4. Remove the dashboard lower cover, then disconnect the foot light connector and lights-on chime connector from the dashboard lower cover.




5. Remove the column covers.



6. Disconnect the connector between the cable reel and SRS main harness.
7. Remove the driver's airbag assembly from the steering wheel, then remove the steering wheel nut.



8. Disconnect the connectors from the horn and cruise control set/resume switches, then remove the cable reel 3P connector from its clips.



9. Remove the steering wheel from the column.
10. Remove the cable reel and cancel sleeve.

