




Roof Side Lock Replacement


CAUTION: To prevent damage, place the roof on an appropriate pad.

1. Remove the roof.
2. Remove the roof front trim and roof side trim (see page 20-82).
3. Install the roof side lock handle.
4. Turn the roof side lock handle, then remove the screws.

►: Screw locations, 3



Apply liquid thread lock.



5. Return the roof side lock handle to the unlocked position, then remove it.


(cont'd)

Roof

Roof Side Lock Replacement (cont'd)

6. Move the roof side lock, then pull the lock pins out and remove the lock.

NOTE: Take care not to bend the rods and lock pins.



7. Installation is the reverse of the removal procedure.

NOTE:

- Grease the location indicated by the arrow and the lock pins.
- Make sure the roof side lock works smoothly.