

Fuel and Emissions

| | |
|--------------------------------|--------|
| Special Tools | 11-2 |
| Component Location Index | |
| '97-99 Models | 11-3 |
| '00-01 Models | 11-3c |
| '02-03 Models | 11-2e |
| '04-05 Models | 11-3 |
| System Description | |
| Vacuum Connections | |
| '97-99 Models | 11-7 |
| '00-05 Models | 11-6c |
| Electrical Connections | |
| '97-99 Models | 11-10 |
| '00-01 Models | 11-9c |
| '02-05 Models | 11-3e |
| System Connectors | |
| Engine Compartment, Right Side | |
| '97-99 Models | 11-24 |
| '00-01 Models | 11-24c |
| '02-05 Models | 11-18e |
| Engine Compartment, Left Side | |
| '97-99 Models | 11-26 |
| '00-01 Models | 11-26c |
| '02-05 Models | 11-20e |
| Behind the Bulkhead Panels | |
| '97-99 Models | 11-28 |
| '00-01 Models | 11-28c |
| '02-05 Models | 11-22e |

| | |
|----------------------------------|--------|
| Front Compartment and Under-dash | |
| '97-99 Models | 11-34 |
| '00-01 Models | 11-34c |
| '02-05 Models | 11-28e |
| Troubleshooting | |
| Troubleshooting Procedures | |
| '97-99 Models | 11-38 |
| '00-05 Models | 11-38c |
| ECM Replacement | 11-8g |
| Symptom Chart | |
| '97-99 Models | 11-42 |
| '00-05 Models | 11-40c |
| Probable Cause List | |
| '97-99 Models | 11-43 |
| '00-05 Models | 11-41c |
| Engine Control Module Terminal | |
| Arrangement | |
| '97-99 Models | 11-46 |
| '00-05 Models | 11-42c |
| DTC Chart | 11-52 |
| How to Read Flowcharts ... | 11-58 |
| PGM-FI System | |
| System Description | 11-59 |
| Troubleshooting Flowcharts | |
| MIL Never Comes On | 11-61 |
| MIL Stays On | 11-62 |

| | |
|-----------------------------------|--------|
| Drive By Wire System | |
| System Description | 11-107 |
| Idle Control System | |
| Troubleshooting Flowcharts | |
| Air Conditioning Signal | 11-118 |
| Alternator (ALT) FR | |
| Signal | 11-120 |
| A/T Gear Position Signal ... | 11-122 |
| Neutral Switch Signal | |
| (M/T) | 11-124 |
| Clutch Switch Signal | |
| (M/T) | 11-125 |
| Brake Switch Signal | 11-125 |
| Starter Switch Signal | 11-128 |
| Idle Speed Setting | 11-129 |
| Fuel Supply System | |
| Fuel Lines | |
| '97-99 Models | 11-130 |
| '00-05 Models | 11-57c |
| System Description | 11-132 |
| Fuel Pressure | 11-132 |
| Fuel Injectors | |
| '97-03 Models | 11-134 |
| '04-05 Models | 11-40g |
| Fuel Injector Resistor (A/T) | 11-136 |
| Fuel Pressure Regulator | 11-137 |
| Fuel Filter | 11-138 |
| Fuel Pump | 11-142 |
| PGM-FI Main Relay | 11-143 |
| Troubleshooting | 11-144 |
| Fuel Tank | 11-147 |

| | |
|---|--------|
| Intake Air System | |
| System Description | 11-148 |
| Air Cleaner | 11-149 |
| Throttle Cable | 11-150 |
| Throttle Body | 11-151 |
| Fuel Injection Air (FIA) Control System | |
| Description | 11-153 |
| Intake Air Bypass (IAB) Control System | |
| Description | 11-154 |
| Troubleshooting | 11-155 |
| Intake Air Bypass (IAB) Control | |
| Valve Testing | 11-157 |
| Emission Control System | |
| System Description | |
| '97-99 Models | 11-158 |
| '00-05 Models | 11-58c |
| Tailpipe Emission | 11-158 |
| Three Way Catalytic Converter | |
| (TWC) System | 11-159 |
| Exhaust Gas Recirculation (EGR) | |
| System | 11-161 |
| Positive Crankcase (PCV) | |
| System | 11-166 |
| Evaporative Emission Controls | |
| Description | 11-167 |
| EVAP Control Canister | |
| Removal/Installation | 11-177 |
| EVAP Two Way Valve Testing .. | 11-178 |
| Pulsed Secondary Air Injection System | |
| Description | 11-73 |