

Trunk Sub-spoiler

Replacement


NOTE: Take care not to scratch the trunk lid and related parts.

1. Apply protective tape to both inside face of the trunk lid spoiler.
2. Open the trunk lid.
3. Remove the trunk sub-spoiler.
 - 1 Remove the trunk striker.
 - 2 Pull the rear edge of the trunk sub-spoiler up by hand, then insert a plastic clip remover between the trunk lid and trunk sub-spoiler in the sequence shown to release the clips.

NOTE:

- Take care not to scratch the painted surface of the trunk lid.
- When releasing the clips of the center area, hold the trunk sub-spoiler by hand to prevent jumping it.

▷ : Clip locations



4. If the old trunk sub-spoiler is to be reinstalled, replace any damaged seals.
5. Replace the grommets with new ones.
6. Installation is the reverse of the removal procedure.