


Front Sensor Replacement

NOTE:

- Be careful when installing the sensors to avoid twisting the wires.
- After sensor replacement confirm proper operation (see page 19-62).

☆: CORROSION RESISTANT BOLT

☆ 6 x 1.0 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)



☆ 6 x 1.0 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)

☆ 8 x 1.25 mm
22 N·m (2.2 kgf·m, 16 lbf·ft)


Rear Sensor Replacement

NOTE:

- Be careful when installing the sensors to avoid twisting the wires.
- After sensor replacement, confirm proper operation (see page 19-62).

☆ 8 x 1.25 mm
22 N·m (2.2 kgf·m, 16 lbf·ft)

☆ 6 x 1.0 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)



☆: CORROSION RESISTANT BOLT

☆ 6 x 1.0 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)

☆ 6 x 1.0 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)