


# Cooling

## Illustrated Index

**⚠ WARNING** System is under high pressure when the engine is hot. To avoid danger of releasing scalding engine coolant, remove the cap only when the engine is cool.

**Total Cooling System Capacity: Including expansion tank**  
2.1 ℓ (2.2 US qt, 1.8 Imp qt)  
M/T: 16.0 ℓ (17.0 US qt, 14.1 Imp qt)  
A/T: 16.5 ℓ (17.4 US qt, 14.5 Imp qt)

### Radiator, Water Pipes and Hoses:



#### NOTE:

- Check all cooling system hoses for damage, leaks or deterioration and replace if necessary.
- Check all hose clamps and retighten if necessary.
- Use new O-rings when reassembling.



### EXPANSION TANK

Refilling and bleeding, page 10-5

Leak Test, page 10-8

### CAP

Test, page 10-8

