



# Opener Cables

## Replacement

1. Remove the openers and latches, then disconnect the opener cables.
2. Remove the fuel lid latch.
3. Remove the opener cables by removing the clips as shown.

**NOTE:**

- Before pulling out the opener cables, tie a string to the opener cable so you can pull it back in later.
- Take care not to bend the opener cables.

4. Installation is the reverse of the removal procedure.

**NOTE:**

- Make sure the opener cables are routed and connected properly.
- If necessary, adjust the opener cables by changing the position of the cable housing.
- If necessary, replace any damaged clips.

