


Power Door Locks

Driver's Door Actuator Test

- 1. Remove the door panel (see [section 20](#)).
- 2. Disconnect the 8P connector from the actuator.



- 3. Test actuator operation:

LOCK: With battery power connected to the No. 7 terminal, connect ground to the No. 8 terminal momentarily.

UNLOCK: With battery power connected to the No. 8 terminal, connect ground to the No. 7 terminal momentarily.

CAUTION: To prevent damage to the motor, connect power and ground only momentarily.

- 4. If the actuator fails to operate properly, replace it.

- 5. Check for continuity between the terminals in each switch position according to the table.

Key Cylinder Switch:

Terminal Position	1	2	3
UNLOCK			
NEUTRAL			
LOCK			

Door Lock Knob Switch:

Terminal Position	4	5	6
LOCK			
UNLOCK			

