



Valve


Assembly

NOTE: Coat all parts with ATF before assembly.

- Install the valve, valve spring and cap in the valve body, then install the roller.




- Set the spring in the valve, and install it in the valve body. Push the spring in with a screwdriver, then install the spring seat.





- Set the spring in the valve, and install it in the valve body. Install the spring with a screwdriver, then install the valve cap with the cutout aligned with the screwdriver.



- Install the valve, spring and cap in the valve body. Push on the cap, then install the stopper seat.

