




Vehicle Speed Sensor (VSS)

Replacement

1. Disconnect the 3P connector from the vehicle speed sensor (VSS).



2. Remove the mounting bolts and the VSS, then take out the VSS assembly.

NOTE: The VSS drive link is a very small part, be careful not to lose it.

3. Install in the reverse order of removal.