

Supplemental Restraint System (SRS)

Airbag Assembly Removal

⚠ WARNING Store a removed airbag assembly with the pad surface up; if the airbag is improperly stored face down, accidental deployment could propel the unit with enough force to cause serious injury.


CAUTION:

- Do not install used SRS parts from another car. When repairing, use only new SRS parts.
- Carefully inspect the airbag assembly before you install it. Do not install an airbag assembly that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.
- Do not disassemble or tamper with the airbag assembly.

1. Before disconnecting any parts of the SRS wire harness, install the short connectors (RED) (see page 24-10).

Driver's Airbag:

2. Remove the two Torx bolts using a Torx T30 bit, then remove the driver's airbag assembly.



Passenger's Airbag:

3. Remove the glove box, then remove the four mounting nuts from the bracket.
4. Remove the bracket and mounting nut from the passenger's airbag assembly.
5. Carefully lift the passenger's airbag assembly out of the dashboard.

