




Foot Well Light Replacement

1. Remove the dashboard lower cover.
2. Disconnect the 2P connector from the foot well light.



3. Push the foot well light out of the dashboard lower cover.
4. Open the foot well light cover, then remove the bulb from the housing.

