



Mainshaft Assembly

Disassembly


1. Support ball bearing on steel blocks as shown, and press the shaft out of the ball bearing. Use of a jaw-type puller can damage the gear teeth.



2. Support 6th gear on steel blocks as shown, and press the shaft out of the ball bearing.



3. Support 5th gear on steel blocks as shown, and press the shaft out of the 5th/6th synchro hub.



4. In the same manner as above, support the 3rd gear on steel blocks, and press the shaft out of the 3rd/4th synchro hub.

