




Mainshaft Assembly

Index

NOTE: The 3rd/4th and 5th/6th synchro hubs are installed with a press.

 Prior to reassembling, clean all the parts in solvent, dry them, and apply lubricant to any contact surfaces. The 3rd/4th and 5th/6th synchro hubs, however, should be installed with a press before lubricating them.

