


Power Door Locks

Keyless Buzzer Test/Replacement

1. Open the hood.
2. Disconnect the 2P connector (A) from the keyless buzzer (B).



3. Test the buzzer by connecting battery power to the No. 2 terminal and grounding the No. 1 terminal. You should hear a slight chirp.
4. If the buzzer fails to sound, remove the two mounting screws, and replace the buzzer.

