


Crankshaft Pulley and Pulley Bolt

Replacement

When installing and tightening the pulley, follow the procedure below.

Clean, remove any oil and lubricate points shown below.

- : Clean
- × : Remove any oil
- : Lubricate



Crankshaft pulley bolt size and torque value:

16 x 1.5 mm
245 N-m (25.0 kgf-m, 181 lbf-ft)

NOTE:

- Do not use an impact wrench when installing.
- Make sure the handle thumb screw aligns with the hole in the attachment.

