


Immobilizer System

Immobilizer Receiver Replacement

1. Remove the dashboard lower cover and dashboard lower pad (see page [23-73](#)).
2. Remove the dashboard brace (see page [23-73](#)).
3. Disconnect the 3P connector from the immobilizer control unit. This harness is shielded and serves as a communication link; be careful not to damage it.
4. Remove the screw from the immobilizer receiver, then remove the receiver from the ignition key cylinder.

IMMOBILIZER RECEIVER



5. Install the new immobilizer receiver in the reverse order of removal.
6. After replacement, check the immobilizer system.