


# Glove Box Light


## Replacement/Test

1. Remove the glove box lower panel.



2. Remove the eight screws, then pull out the glove box.
3. Disconnect the 2P connectors, then remove the glove box.

4. Remove the two screws from the glove box light.



5. Check for continuity between the A terminal and B terminal with a bulb installed. There should be continuity. There should be no continuity when the switch plunger is pushed.

